ENGLISH

G7 PRO 8K

WIRELESS ESPORTS CONTROLLER FOR PC

Model No.: GameSir-G7 Pro 8K
Scan the code for more tutorials ➡
https://gamesir.com/pages/support

COMPATIBILITY

•Windows 10 or above •Switch1 & 2 •Android 11.0 or above

DEVICE LAYOUT

BASIC FUNCTION INTRODUCTION

BASIC OPERATIONS

Power On	Toggle the Mode Switch to the corresponding position and press the Home button.
Power Off	Toggle the Mode Switch to the Off position or the device will automatically turn off after 10 minutes of inactivity.
Low Battery	When the battery is below 15%, the Home light will flash red.
Charging	You can charge the controller via the USB-C port or the charging station. When charging while the controller is off, the Home light will indicate the charging progress with a breathing light effect.

CONNECTION STATUS

Status	Home Light	Description
Connected	Solid	The device is successfully connected.
Pairing	Flash Rapidly	In pairing status, the controller can be discovered and connected by new devices.
Reconnecting	Breathe Slowly	In reconnecting status, the controller can automatically connect to the last successfully connected device. Press and hold the Pairing button to manually enter pairing mode.

PLATFORM AND MODE

WIRELESS CONNECTION

Platform	Mode Switch Position	Mode	Indicator Light Color	Switch Method
PC/Switch/Android	Receiver Mode	Receiver	Green	Toggle to Receiver mode.
PC/Android/AP	Bluetooth Mode	DS4	Blue	Toggle to Bluetooth mode, then **Home button + ⏻** for 2 seconds. Hold Hold
Switch/AP		Switch	Red	Toggle to Bluetooth mode, then **Home button + ⏻** for 2 seconds. Hold Hold
Android		Android	Yellow	Toggle to Bluetooth mode, then **Home button + ⏻** for 2 seconds. Hold Hold

WIRED/RECEIVER CONNECTION

Platform	Mode	Indicator Light Color	Switch Method
PC Xinput Mode	Green	**Wired connection:** In any mode, connect the controller to the device using the USB-C cable. No additional steps needed. **Receiver connection:** Toggle the Mode Switch to Receiver mode.
Switch	Switch Mode	Red	
Android	DS4 Mode	Blue	The controller will automatically detect the mode by default. After a successful connection, press and hold ⏻ for 3 seconds to cycle through Xinput/Switch/DS4 modes.

* After a successful connection, the current mode can be checked by pressing and holding the M button.

WINDOWS CONNECTION TUTORIAL

RECEIVER CONNECTION

1.Toggle the Mode Switch on the controller to Receiver mode ● ● and press the Home button to power on.
2.Insert the included receiver into the device's USB port and wait for the controller to connect.
3.A solid Home light indicates a successful connection.
__If the connection fails, hold the Pairing button__ on the controller to re-enter pairing mode.__

SWITCH 1 & 2 CONNECTION TUTORIAL

1.On the Switch main menu, go to "Controllers"-"Change Grip/Order".
2.Toggle the Mode Switch on the controller to Switch mode ● ● and press the Home button to power on.
3.A solid Home button + ✥ until the Home light flashes rapidly in red and wait for the connection.
4.A solid Home light indicates a successful connection.
__If the connection fails, hold the Pairing button__ on the controller to re-enter pairing mode.__

SWITCH 2 WAKE-UP TUTORIAL

1.Switch both sides of Joy-Con 1 to the Grip/Order interface.
2.On the Switch 2 main menu, tap the controller icon and select [Change Grip/Order] to enter pairing mode.
3.After the controller is successfully connected to the Switch 2, it cannot be operated yet. On "Change Grip/Order", press any button (e.g., Touch), at the bottom, then tap the icon of any Joy-Con 2. When the controller vibrates, the wake-up function has been successfully activated.
__This process is only required for the first-time setup.__

ANDROID CONNECTION TUTORIAL

1.Toggle the Mode Switch on the controller to Bluetooth mode ● ● and press the Home button to power on.
2.Hold **Home button + ✥** until the Home light flashes rapidly in yellow. Find "GameSir-G7 Pro 8K" in the device's Bluetooth list and click to connect.
3.A solid Home light indicates a successful connection.
__If the connection fails, hold the Pairing button__ on the controller to re-enter pairing mode.__

AP CONNECTION TUTORIAL

1.Toggle the Mode Switch on the controller to Bluetooth mode ● ● and press the Home button to power on.
2.Hold **Home button + ✥** until the Home light flashes rapidly in blue. Find "DualShok 4 Wireless Controller" in the device's Bluetooth list and click to connect.
3.A solid Home light indicates a successful connection.
__If the connection fails, hold the Pairing button__ on the controller to re-enter pairing mode.__

ADVANCED TUTORIAL

Function	Button Combination	Description
Manually Switch Mode	✥ + ⏻ for 2 seconds Hold Hold	Press and hold the View and Menu buttons simultaneously for 2 seconds to cycle through Xinput/Switch/DS4 modes. * Only available in receiver and wired connection modes.
Macro Button Settings	M + L4/R4/L5/R5 Hold Press	Press and hold the M and L4/R4/L5/R5 simultaneously until the Home light starts flashing in white. Press the button to be programmed. Then, press L4/R4/L5/R5 again to save and exit. * You can record up to 32 steps. * If you exit the setting process without pressing any button, the current assignment for that macro button will be cleared.
Configuration Switch	M + ✥ Hold Toggle	Configuration 1: M + toggle the right stick upward. Configuration 2: M + toggle the right stick to the left. Configuration 3: M + toggle the right stick to the right. Configuration 4: M + toggle the right stick downward.
Dead Zone Toggle	M + ⏻ 3 sec Hold Hold	Hold the M button and press down the left/right stick for 2 seconds to toggle the corresponding stick's dead zone on or off.
Turbo	M + ✥ + corresponding buttons Hold Press	While holding the M button, press A/B/X/Y/LB/RB/LT/RT to activate the Turbo function for that button. Repeat this operation to cycle through Turbo Off - Turbo level 1 - Turbo level 2 - Turbo level 3. * Double-click the M button to clear all Turbo settings.
Hair Trigger Mode	M + ⏻ for 2 seconds Hold Hold	With the trigger in long-travel mode, press and hold M and LT/RT for 2 seconds to toggle the hair trigger mode on or off. * The trigger must be in long-travel mode.
Vibration Adjustment	M + ✥ / ⏻ Hold Press	While holding the M button, press View / Menu button to decrease/increase the vibration intensity level.
Layout Switch	M + ✥ 2 sec Hold Hold	Press and hold the M and A buttons for 2 seconds to swap the button values of A-B and X-Y.

CALIBRATION

STICKS & TRIGGERS

Set the triggers to long-travel mode. Hold ✥ + **Home button** for 2 seconds to enter calibration mode. The Home light will flash slowly in white during this process.
Ensure the triggers and sticks are not being touched. Press ✥ once.
Rotate both sticks in full circles 2-3 times. Fully press both triggers three times. Finally, press ✥ to exit. The Home light will return to its original light effect.

Gyroscope

Place the controller on a stable, flat surface. Hold **M** + **Y** for 2 seconds to start calibration. During the process, the Home light will flash red and blue alternately. When the light returns to its original effect, calibration is complete.

CONTROLLER RESET

If the wireless/wired connection controller buttons, you can use a small object similar to the slot of a paperclip to press the Reset button inside the circular hole on the back of the controller. This will force the controller to power off.

PLEASE READ THIS PRECAUTIONS CAREFULLY

- CONTAINS SMALL PARTS. Keep out of reach of children under the age of 3. Seek immediate medical attention if swallowed or inhaled.
- DO NOT use the product near fire.
- DO NOT expose the product to high or high temperature.
- DO NOT leave the product in a humid or dusty environment.
- DO NOT impact or drop the product or cause it to fall due to strong impact.
- DO NOT touch USB port directly or it might cause malfunctions.
- DO NOT attempt to take apart or publish.
- Use a soft, dry cloth while cleaning.
- DO NOT clean the product with any gasoline or thinner.
- DO NOT disassemble, repair or modify!
- Use the product only with the USB cable in original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
- DO NOT look directly at the optical light. It might damage your eyes.
- If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

WASTE ELECTRICAL & ELECTRICAL EQUIPMENT INFORMATION

CORRECT DISPOSAL OF THIS PRODUCT (WASTE ELECTRICAL & ELECTRICAL EQUIPMENT)

Applicable in the European Union and other European countries with separate collection systems.

This mark on the product or accompanying documents means that it should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product to designated collection points where it will be accepted free of charge. Alternatively, in some countries you may be able to return your products to your local retailer upon purchase of an equivalent new product. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could arise from inappropriate waste handling. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier for further information. If you do so, you will ensure that your disposed product undergoes the necessary treatment, recovery and recycling and thus prevents potential negative environmental effects on the environment and human health.

DECLARATION OF CONFORMITY

FC FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.
RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

⚠ CAUTION!

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

CE STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Hereby, Guangzhou Chicken Run Network Technology Co., Ltd. declares that this GameSir G7 Pro 8K Controller is in compliance with Directive 2014/30/EU, 2014/53/EU and 2011/65/EU and its Amendment (EU) 2015/863.

The power provided by the charger is between the minimum 1W required by the radio device and the maximum 5W to achieve the maximum charging speed.

WARNINGS AND SAFETY INFORMATION

All information regarding the use of the products can be found in the attached user manual.
Before using the product, please read the manual carefully and follow the manufacturer's recommendations. Also, please review the following safety information and warnings before use:

USAGE WARNINGS

RISK OF DEVICE DAMAGE:

- Controllers should be used exclusively for their intended purpose—video games. Do not use the device for any purpose other than those recommended by the manufacturer.
- If the device comes into contact with liquid, immediately disconnect it and dry it according to the manufacturer's instructions.
- Avoid applying excessive force when pressing buttons or operating the controller to prevent damage to the mechanisms.

RISK TO THE USER:

- During gameplay, be sure to take regular breaks to avoid fatigue in your hands, wrists, and shoulders.
- Ensure the controller is placed securely to prevent it from slipping or tipping over during use.
- Keep controllers away from electronic systems that may generate sudden movements—simply hold them with both hands and avoid pressing buttons.

POWER AND CONNECTION RISKS:

- Do not use damaged power cables or USB cables. Always use the original accessories provided by the manufacturer.
- Do not charge the controller in environments with temperatures outside the range of 0°C to 45°C (32°F to 113°F).
- For wireless devices, regularly charge the batteries or replace them with new ones to ensure continuous operation.

PROPER USAGE INFORMATION

PREPARATION AND SETUP:

- Before first use, charge the controller or drivers provided by the manufacturer if required.
- Place the controller on a stable surface, such as a desk, to ensure comfort and precision during use.
- Keep cables and wireless receivers out of reach of children to prevent accidental disconnections.

SAFE USAGE:

- Adjust the device settings in games (e.g., sensitivity, vibrations) according to your preferences to ensure comfort and avoid strain on your hands or shoulders.
- Do not modify the controller, its components, batteries, and other components to ensure they are functioning properly.
- Use controllers with force feedback, ensure the feedback settings are not excessive.

ADDITIONAL PRECAUTIONS:

- Cleaning and Maintenance: Regularly remove dust from the controller using a dry, soft cloth. Avoid using harsh chemicals or moisture, as these can damage the internal components.
- Storage: After use, disconnect the controller from the console or PC and store it in a dry, dust-free place.
- Cable Management: Do not coil cables tightly or damage them. Store them in a way that prevents tangling or damage.

COMPLIANCE DECLARATION

Guangzhou Chicken Run Network Technology Co., Ltd. declares that the safety requirements outlined in Directive (EU) 2022/1388, they meet the requirements for electromagnetic compatibility (EMC), durability, and user safety.
This manual or its translations in different languages can be downloaded from the manufacturer.
Detailed information regarding the distributor/manufacturer warranty conditions is available on the website: https://gamesir.com
The product cannot be regularly serviced/maintained by the user or through specialized services due to its design. Any repair and maintenance should be carried out responsibly. If the user manual does not provide information about necessary periodic or service maintenance actions, the physical condition of the product should be assessed annually (at least once a week) to detect any deviation from the condition of a new product. If any deviation is detected or identified, immediately withdraw it from use. Cleaning or servicing activities that do not require the product to be taken apart (cleaning) and respond to identified issues may result in permanent damage to the product. The warranty period for the product is 12 months from the date of purchase, resulting from repairs.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.
RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

⚠ CAUTION!

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

CE STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Hereby, Guangzhou Chicken Run Network Technology Co., Ltd. declares that this GameSir G7 Pro 8K Controller is in compliance with Directive 2014/30/EU, 2014/53/EU and 2011/65/EU and its Amendment (EU) 2015/863.

The power provided by the charger is between the minimum 1W required by the radio device and the maximum 5W to achieve the maximum charging speed.

Battery Information	
Type: Polymer lithium-ion battery pack	Battery Model: PL103048
Battery Category: Rechargeable battery	Battery Capacity: 1500mAh, 4.44Wh
Battery Net Weight: 31.07Sg	Nominal Voltage: 3.7V
Manufacturer: Shenzhen Ultra-Power Technology Co., Ltd. Address: Room 201, building 3, No. 5, Chuangye 4th Road, Zhanglan community, Longcheng Street, Longgang District, Shenzhen Made in China	
Precautions: Do not disassemble, crush, puncture, or expose the battery to fire or high temperatures. If the battery swells or deforms, stop using the product immediately. Do not use the battery if it has been exposed to water or other liquids. Avoid dropping or striking the battery to prevent damage.	

繁體中文

G7 PRO 8K

WIRELESS ESPORTS CONTROLLER FOR PC

型號: GameSir-G7 Pro 8K
搞搞懂如更多教程 ➡
https://gamesir.com/pages/support

適用平臺

•Windows 10或更高版本 •Switch 1&2 •Android 11.0或更高版本

設備佈局

基礎功能介紹

基礎操作

開機	將模式開關撥動至對應模位並單擊Home鍵 ● ●
關機	將模式開關撥動至關閉位 ● ● ，或10分鐘無操作
低電	手柄電量低於15%時，Home燈以紅色閃爍提示
充電	可透過手柄USB-C介面或充電底座給手柄進行充電。 關機狀態下連接時手柄Home燈呼吸燈效果指示電量

連接狀態

狀態	Home燈	說明
連接成功	常亮	指南已連線成功
配對	快速閃爍	處於配對狀態時，可以被新設備搜索、連接
回連	慢速呼吸	處於回連狀態時，可以自動連接上一個連接成功的設備 長按配對鍵，可強制回連配對狀態

平臺和模式

無線連接

使用平臺	模式開關位置	模式	模式燈顏色	切換方式
PC/Switch/Android	接收器模式	接收器	綠色	撥動至接收器模式
PC/Android/AP	藍牙模式	DS4	藍色	撥動至藍牙模式，**Home鍵 + ⏻** 2秒 按住 按住
Switch/AP		Switch	紅色	撥動至藍牙模式，**Home鍵 + ⏻** 2秒 按住 按住
Android		Android	黃色	撥動至藍牙模式，**Home鍵 + ⏻** 2秒 按住 按住

有線/接收器連接

使用平臺	模式	模式燈	模式切換
PC Xinput模式	綠色	**有線連接:** 任意模位下，通過Type-C數據線連接手柄與主機即可。 **接收器連接:** 撥動至接收器模式 ● ●
Switch Switch模式	紅色	
Android DS4模式	藍色	預設自動識別模式，連接成功即可記憶連接模位 ✥ + ⏻ 2秒切換Xinput/Switch/DS4模式循環回圈切換模式。

*連接成功後可以透過單獨按住M鍵查看當前模式

Windows連接教程

接收器連接

1.將模式開關撥動至接收器模位 ● ● 並單擊Home鍵開機。
2.將附贈的接收器插入電腦USB接口，等待手柄連接。
3.Home燈常亮代表連接成功。
*__如果連接成功，需要單擊神設置對應遊戲具有手柄配對設置教程進入配對狀態__

有線連接

使用Type-C數據線連接手柄與電腦。

藍牙連接

1.將手柄的模式開關撥動至藍牙模 ● ● 並單擊Home鍵開機。
2.按住 **Home鍵 + ✥** 3秒or在電腦系統藍牙設置中，搜索手柄名稱"GameSir-G7 Pro 8K"並點擊連接。
3.Home燈常亮代表連接成功。
*__如果連接成功，需要長按手柄配對鍵 ⏻ 重新進入配對狀態__

Switch 2免線教程

1.將Switch 2主機保持在Joy-Con 2配對。
2.在Switch 2主介面點擊手柄圖示並進入「更改握法/順序」。
3.將手柄的模式開關撥動至藍牙模 ● ● 並單擊Home鍵開機。
4.Home燈常亮代表連接成功。
*__如果連接成功，需要長按手柄配對鍵 ⏻ 重新進入配對狀態__

Switch 1&2連接教程

1.將手柄的模式開關撥動至藍牙模 ● ● 並單擊Home鍵開機。
2.按住 **Home鍵 + ✥** 3秒or在電腦系統藍牙設置中，搜索手柄名稱"GameSir-G7 Pro 8K"並點擊連接。
3.Home燈常亮代表連接成功。
*__如果連接成功，需要長按手柄配對鍵 ⏻ 重新進入配對狀態__

Android連接教程

1.將手柄的模式開關撥動至藍牙模 ● ● 並單擊Home鍵開機。
2.按住 **Home鍵 + ✥** 3秒or在電腦系統藍牙設置中，搜索手柄名稱"DualShok 4 Wireless Controller"並點擊連接。
3.Home燈常亮代表連接成功。
*__如果連接成功，需要長按手柄配對鍵 ⏻ 重新進入配對狀態__

AP連接教程

1.將手柄的模式開關撥動至藍牙模 ● ● 並單擊Home鍵開機。
2.按住 **Home鍵 + ✥** 3秒or在電腦系統藍牙設置中，搜索手柄名稱"DualShok 4 Wireless Controller"並點擊連接。
3.Home燈常亮代表連接成功。
*__如果連接成功，需要長按手柄配對鍵 ⏻ 重新進入配對狀態__

進階教程

功能	組合鍵	說明
強制切換模式	✥ + ⏻ 2秒 按住 按住	同時按住視窗鍵和菜單鍵2秒可以在Xinput/Switch/DS4之間強制切換模式。 *即可強力式僅在連接教程有線模式下生效
拓展鍵設定	M + L4/R4/L5/R5 按住 單擊	同時按住M和L4/R4/L5/R5至Home燈由白變橙， 松開單獨編程按鍵，再次按下L4/R4/L5/R5即可退出宏錄製。 *最多錄製32步
配置切換	M + ✥ 按住 撥動	配置1:M+右搖杆上滑 配置2:M+右搖杆左滑 配置3:M+右搖杆右滑 配置4:M+右搖杆下滑
開關死區	M + L3/R3 2秒 按住 單擊	長按M鍵同時左/右搖杆的搖杆下壓2秒，可以關閉對應搖杆死區。
連發	M + 對應按鍵 按住 單擊	按住M鍵的同時單擊A/B/X/Y/LB/RB/LT/RT即可開啟該按鍵的連發 單擊連發即可在關閉/1檔/2檔/3檔之間切換 *雙M鍵可清除所有連發設置
扳機鎖定	M + L3/R3 按住 單擊	短按M鍵的同時單擊L3/R3可以開啟/關閉扳機鎖定模式，可用手柄背面鍵操作
震動強度	M + 方向鍵上/下 按住 單擊	按住M鍵的同時單擊方向鍵上/下鍵，可以調整震動強度
佈局切換	M + A 2秒 按住 按住	按住M鍵的同時單擊A鍵2秒，可以互換A-B, X-Y的鍵值

校準

搖桿校準

將搖桿與扳機切換至長行程模式，同時按住 ✥ + **Home鍵** 2秒進入校準模式，進入時Home燈會亮橙色。
確保不要觸碰扳機和搖桿的情況下，單擊一次 ✥ 。
旋轉左右搖桿各圈2-3圈，完全按下扳機3次，最後單擊一次 ✥ 退出校準模式，Home燈恢復原始狀態。

陀螺儀

將手柄放置在穩定的平面桌面，同時按住 **M** + **Y** 2秒開始校準，進入時Home燈會亮橙色。
校準過程中Home燈會交替閃爍紅色和藍色，當燈光恢復為原始狀態時，校準完成。

⚠ 使用前請務必閱讀本注意事項

- 內含微小零件，請務必遠離3歲以下兒童避免不到的地方，若不慎吞食或吸入，請立即就醫。
- 請勿靠近火源使用產品。
- 請勿將產品置於潮濕或高粉塵或高溫的環境中。
- 請勿施加重力衝擊或摔落產品，以免造成損壞。
- 請勿將產品碰觸到水或液體。
- 請勿直接接觸USB插口，否則可能會導致故障。
- 請勿嘗試拆卸或出版。
- 請勿使用汽油或稀釋劑等易燃物品。
- 清潔時請使用乾燥的軟布。
- 請勿使用汽油或稀釋劑等易燃物品。
- 請勿自行拆卸、維修或改裝！
- 請勿將產品用於原本設計用途以外的用途，對用於非原本用途而造成的事故或損壞，我們概不負責。
- 請勿直視光源，可能會傷害您的眼睛。
- 如果您有任何有關產品品質的問題或建議，請聯繫GameSir或您當地的經銷商。

產品型號:GameSir-G7 Pro 8K

「取得審驗證明之位功率對照組件，申請核准，以利」將被認定用途或不得自從新採用，加大功率認證要求並設計消耗及加大，或是取得審驗證明之位功率對照組件，申請核准，以利」將被認定用途或不得自從新採用，推立即停用，並改善至用下確用方得繼續使用，前述作法適性，指根電信管理法規定作業之無線電通訊，低功率射頻器材須符合下列規定：經型式認證合格之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫用電波輻射性電機設備之干擾。

ENGLISH

RISK TO THE USER:

- During gameplay, be sure to take regular breaks to avoid fatigue in your hands, wrists, and shoulders.
- Ensure the controller is placed securely to prevent it from slipping or tipping over during use.
- Keep controllers away from electronic systems that may generate sudden movements—simply hold them with both hands and avoid pressing buttons.

POWER AND CONNECTION RISKS:

- Do not use damaged power cables or USB cables. Always use the original accessories provided by the manufacturer.
- Do not charge the controller in environments with temperatures outside the range of 0°C to 45°C (32°F to 113°F).
- For wireless devices, regularly charge the batteries or replace them with new ones to ensure continuous operation.

PROPER USAGE INFORMATION

PREPARATION AND SETUP:

- Before first use, charge the controller or drivers provided by the manufacturer if required.
- Place the controller on a stable surface, such as a desk, to ensure comfort and precision during use.
- Keep cables and wireless receivers out of reach of children to prevent accidental disconnections.

SAFE USAGE:

- Adjust the device settings in games (e.g., sensitivity, vibrations) according to your preferences to ensure comfort and avoid strain on your hands or shoulders.
- Do not modify the controller, its components, batteries, and other components to ensure they are functioning properly.
- Use controllers with force feedback, ensure the feedback settings are not excessive.

ADDITIONAL PRECAUTIONS:

- Cleaning and Maintenance: Regularly remove dust from the controller using a dry, soft cloth. Avoid using harsh chemicals or moisture, as these can damage the internal components.
- Storage: After use, disconnect the controller from the console or PC and store it in a dry, dust-free place.
- Cable Management: Do not coil cables tightly or damage them. Store them in a way that prevents tangling or damage.

COMPLIANCE DECLARATION

Guangzhou Chicken Run Network Technology Co., Ltd. declares that the safety requirements outlined in Directive (EU) 2022/1388, they meet the requirements for electromagnetic compatibility (EMC), durability, and user safety.
This manual or its translations in different languages can be downloaded from the manufacturer.
Detailed information regarding the distributor/manufacturer warranty conditions is available on the website: https://gamesir.com
The product cannot be regularly serviced/maintained by the user or through specialized services due to its design. Any repair and maintenance should be carried out responsibly. If the user manual does not provide information about necessary periodic or service maintenance actions, the physical condition of the product should be assessed annually (at least once a week) to detect any deviation from the condition of a new product. If any deviation is detected or identified, immediately withdraw it from use. Cleaning or servicing activities that do not require the product to be taken apart (cleaning) and respond to identified issues may result in permanent damage to the product. The warranty period for the product is 12 months from the date of purchase, resulting from repairs.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.
RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

⚠ CAUTION!

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

CE STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Hereby, Guangzhou Chicken Run Network Technology Co., Ltd. declares that this GameSir G7 Pro 8K Controller is in compliance with Directive 2014/30/EU, 2014/53/EU and 2011/65/EU and its Amendment (EU) 2015/863.

The power provided by the charger is between the minimum 1W required by the radio device and the maximum 5W to achieve the maximum charging speed.

Battery Information	
Type: Polymer lithium-ion battery pack	Battery Model: PL103048
Battery Category: Rechargeable battery	Battery Capacity: 1500mAh, 4.44Wh
Battery Net Weight: 31.07Sg	Nominal Voltage: 3.7V
Manufacturer: Shenzhen Ultra-Power Technology Co., Ltd. Address: Room 201, building 3, No. 5, Chuangye 4th Road, Zhanglan community, Longcheng Street, Longgang District, Shenzhen Made in China	
Precautions: Do not disassemble, crush, puncture, or expose the battery to fire or high temperatures. If the battery swells or deforms, stop using the product immediately. Do not use the battery if it has been exposed to water or other liquids. Avoid dropping or striking the battery to prevent damage.	

DEUTSCH

G7 PRO 8K

WIRELESS ESPORTS CONTROLLER FOR PC

Modellname: GameSir-G7 Pro 8K
Code für weitere Anleitungen scannen ➡
https://gamesir.com/pages/support

KOMPATIBILITÄT

•Windows 10 oder höher •Switch 1 & 2 •Android 11.0 oder höher

GERÄTELAYOUT

EINFÜHRUNG IN BASISFUNKTIONEN

BEDIENUNGSGRUNDLAGEN

Einschalten	Schieber der Modusauswahltaste in die Zeit-Position ● ● und drücke die Home-Taste.
Ausschalten	Schieber der Modusauswahltaste in die Aus"-Position ● ● Anderfalls schaltet sich das Gerät automatisch nach 10 Minuten Inaktivität ab.
Niedriger Akkustand	Wenn der Akku weniger als 15 % Restleistung aufweist, blinkt die Home-LED-Anzeige rot.
Aufladen	Du kannst den Controller über den USB-C-Anschluss oder die Ladestation aufladen. Wenn du den Controller ausgeschaltet lädst, zeigt die Home-LED-Anzeige den Ladestatus über einen pulsierenden Farbeffekt wider.

VERBINDUNGSSTATUS

Status	Home-LED-Anzeige	Beschreibung
Verbindung hergestellt	Leuchtet durchgehend	Das Gerät wurde erfolgreich verbunden.
Kopplung	Blinkt schnell	Im Kopplungsmodus kannst du nach neuen Geräten suchen und den Controller koppeln.
Neuverbinden	Pulsiert langsam	Der Controller kann im Wiederverbindungsmodus automatisch mit dem zuletzt erfolgreich verbundenen Gerät verbunden werden. Halte die Kopplungstaste gedrückt, um den Kopplungsmodus manuell zu starten.

PLATTFORMEN UND MODI

KABELLOSE VERBINDUNG

Plattform	Modusschalter-Position	Modus	LED-Anzeigenfarbe	Umschaltmethode
PC/Switch/Android	Empfängermodus	Empfänger	Grün	Wechsle in den Empfängermodus.
PC/Android/AP	Bluetooth-Modus	DS4	Blau	Wechsle in den Bluetooth-Modus und halte die **Home-Taste** + ✥ 2 Sekunden lang gedrückt.
Switch/AP		Switch	Rot	Wechsle in den Bluetooth-Modus und halte die **Home-Taste** + ✥ 2 Sekunden lang gedrückt.
Android		Android	Gelb	Wechsle in den Bluetooth-Modus und halte die **Home-Taste** + ✥ 2 Sekunden lang gedrückt.

KABELGEBUNDENE/EMPFÄNGERVERBINDUNG

Plattform	Modus	LED-Anzeigenfarbe	Umschaltmethode
PC Xinput-Modus	Grün		**Kabelgebundene Verbindung:** Verbinde den Controller in einem beliebigen Modus über ein USB-C-Kabel mit dem Gerät. Es sind keine weiteren Schritte erforderlich.
Switch Switch-Modus	Rot		**Empfängerverbindung:** Wechsle per Modusschalter in den Empfängermodus ● ●
Android DS4-Modus	Blau		Der Controller erkennt den Modus standardmäßig automatisch. Halte nach der erfolgreichen Verbindung ✥ + ⏻ noch einmal 3 Sek. lang gedrückt, um die Xinput-/Switch-/DS4-Modi durchzuschalten.

* Dieser Vorgang ist nur für die Ersteinrichtung erforderlich.

KALIBRIERUNG

STICKS UND TRIGGER

Stelle die Trigger-Tastatur auf „Long" ein. Halte ✥ + **Home-Taste** 2 Sek. lang gedrückt, um den Kalibrierungsmodus zu aktivieren. Die Home-LED-Anzeige blinkt während dieses Vorgangs langsam weiß.
Berühre dabei keinesfalls die Trigger-Tasten oder die Sticks. Drücke ✥ einmal.
Drehe beide Sticks 2- bis 3-mal um die eigene Achse. Drücke im Anschluss beide Trigger-Tasten 3-mal vollständig durch. Drücke zum Abschluss ✥ . Die Home-LED-Anzeige wechselt daraufhin wieder in den vorherigen Modus.

GYROSKOP

Lege den Controller auf eine flache Oberfläche. Halte **M** + **Y** 2 Sek. lang gedrückt, um den Kalibrierungsmodus zu aktivieren.
Während der Kalibrierung blinkt die Home-LED-Anzeige abwechselnd rot und blau. Wenn die LED-Anzeige wieder in der vorherigen Farbe leuchtet, ist die Kalibrierung abgeschlossen.

ZURÜCKSETZEN DES CONTROLLERS

Wenn Controller-Tasten nicht mehr reagieren, kannst du einen kleinen Gegenstand, z. B. eine Büroklammer, in das Loch zum Zurücksetzen des Controllers drücken, um den Reset-Taster zu betätigen. Dadurch wird der Controller ausgeschaltet und zurückgesetzt.

⚠ BITTE LES DIR DIE SICHERHEITSHINWEISE AUFMERKSAM DUR

GAMESIR

한국어

G7 PRO 8K

WIRELESS ESPORTS CONTROLLER FOR PC

모델 번호: GameSir-G7 Pro 8K
코드를 스캔하여 추가 사용 방법을 확인하십시오 ➡
https://gamesir.com/pages/support

호환성

•Windows 10 및 이후 버전 •Switch 1 & 2 •Android 11.0 이상

장치 레이아웃

기본 기능 소개

기본 동작

전원 켜기	모드 스위치 휠을 약 1초 동안 전환한 후, Home 버튼을 누릅니다.
전원 끄기	모드 스위치를 USB 포트(중앙)로 약 3초 동안 길게 누릅니다.
배터리 부족	배터리가 15% 이하이면 Home 표시등이 깜박이고 경고합니다.
충전	USB-C 포트나 충전 스테이션으로 컨트롤러를 충전할 수 있습니다. 컨트롤러가 켜진 상태에서 충전하면, Home 표시등 외이드 조명 효과 중단 상태를 표시합니다.

연결 상태

상태	Home 조명	설명
연결 완료	점등	장치가 연결되었습니다.
페어링	빠르게 점멸	페어링 상태에서는 컨트롤러를 세 장치로 검색하며 연결합니다.
재연결	느린 3번	저전량 상태에서 컨트롤러를 켜거나 모드를 변경하면 3번 깜박입니다. 페어링 버튼을 길게 눌러 페어링 모드로 수동 전환합니다.

플랫폼 및 모드

무선 연결

플랫폼	모드 스위치 위치	모드	표시등 색상	전원 방법
PC/Switch/Android	마지막 모드			
PC/Android/AP	블루투스 모드	D54	파란색	블루투스 모드로 전환한 후, **Home 버튼** + ◁ 또는 ▷ 2초간 길게 누릅니다.
Switch/AP		Switch	빨간색	
Android		D54	노란색	

유선/리시버 연결

플랫폼	모드	표시등 색상	전원 방법
PC	Xinput 모드	초록색	**유선 연결:** 위쪽 모드 케이블 USB-C 케이블로 장치와 컨트롤러를 연결합니다. 추가 조작은 필요하지 않습니다.
Switch	Switch 모드	빨간색	**리시버 연결:** 리시버를 Switch 또는 PC USB 포트에 꽂습니다.
Android	D54 모드	파란색	컨트롤러는 기본적으로 모드를 자동 전환합니다. 변경 후 **Home 버튼** + ◁ 또는 ▷ 2초간 길게 눌러 Xinput/Switch/D54 모드를 전환합니다.

* 연결 후, 버튼을 길게 눌러 전원 모드를 확인할 수 있습니다.

Windows 연결 방법

리시버 연결

1. 컨트롤러의 모드 스위치를 리시버 모드 ⓓ ● 로 전환한 후, Home 버튼을 눌러 전원을 켭니다.
2. 동글을 PC 또는 노트북의 USB 포트에 삽입합니다. 컨트롤러가 연결되면 Home 표시등이 켜집니다.
3. 연결되면 Home 조명이 켜집니다.

*** 연결되지 않으면 리시버 페어링 버튼을 누르고 컨트롤러 페어링 버튼을 길게 누른 후 페어링 모드로 재연결합니다.**

유선 연결

1. 모드 스위치를 PC 모드(중앙)로 전환합니다.
2. 케이블을 컨트롤러와 PC 또는 노트북에 연결합니다.

블루투스 모드

1. 컨트롤러의 모드 스위치를 블루투스 모드 ⓑ ● 로 전환한 후, Home 버튼을 눌러 전원을 켭니다.
2. 컨트롤러 페어링 모드에 들어가려면 **Home 버튼** + ◁ 또는 ▷ 버튼을 길게 누릅니다. 장치의 블루투스 목록에서 검색 "Wireless Controller" 를 선택한 후 연결을 끝내십시오.
3. 연결되면 Home 조명이 켜집니다.

*** 연결되지 않으면 컨트롤러의 페어링 버튼 ⓒ 을 길게 눌러 페어링 모드로 재연결합니다.**

Switch 2 대기 모드 해제 방법

1. Switch 2에서 [홈] 메뉴 > Joy-Con 2를 모두 분리합니다.
2. 컨트롤러의 모드 스위치를 블루투스 모드 ⓑ ● 로 전환한 후, Home 버튼을 눌러 전원을 켭니다.
3. Home 조명이 켜지면 Home 버튼 + ◁ 또는 ▷ 버튼을 길게 누릅니다. 장치 목록에서 "Wireless Controller"를 선택하여 연결합니다.
4. 연결되면 Home 조명이 켜집니다.

*** 연결되지 않으면 컨트롤러의 페어링 버튼 ⓒ 을 길게 눌러 페어링 모드로 재연결합니다.**

Android 연결 방법

1. 컨트롤러의 모드 스위치를 블루투스 모드 ⓑ ● 로 전환한 후, Home 버튼을 눌러 전원을 켭니다.
2. Home 조명이 빠르게 깜박이면 페어링 모드에 들어간 것입니다. 장치의 블루투스 목록에서 "Gamesir-G7 Pro 8K_2" 장치 연결을 클릭합니다.
3. 연결되면 Home 조명이 켜집니다.

*** 연결되지 않으면 컨트롤러의 페어링 버튼 ⓒ 을 길게 눌러 페어링 모드로 재연결합니다.**

고급 설정 방법

기능	버튼 조합	설명
수동 전환 모드	Ⓜ + ◁ 또는 ▷	View 버튼과 Menu 버튼을 6초간 동시 눌러 Xinput/Switch/D54 모드를 전환합니다. (Android 및 윈도우 모드 전환 지원)
매크로 버튼 설정	M + L4/R4/L5/R5	Home 조명이 천천히 2 회 깜박일 때까지 버튼을 L4/R4/L5/R5 중 하나를 누릅니다. 녹화 시작: 3 번 깜박임. 녹화 완료: 2 번 깜박임. L4/R4/L5/R5 버튼을 다시 눌러 저장하고 종료합니다. * 5 회 누르면 녹화 가능. 총 10 개까지 * 장치 재부팅 시 녹화 설정 및 매크로 내용은 삭제됩니다.
설정 전환	M + (R) 길게 누르기	방향 1: M + 오른쪽 스틱 위로 방향 2: M + 오른쪽 스틱 아래로 설정 3: M + 오른쪽 스틱 왼쪽으로 설정 4: M + 오른쪽 스틱 오른쪽으로
마이크 토글	M + 짧게 누르기	M 버튼을 길게 누른 상태에서 짧게 누르면 음소거 또는 음소거 해제
터보	M + 앞쪽 버튼 길게 누르기	M 버튼을 누른 상태로 A/B/X/Y/LB/RB/LT/RT 을 눌러 터보 기능을 활성화합니다. 속도 조절: 동시에 Home 조명이 깜박일 때까지 M 버튼을 누른 상태로 A/B/X/Y 버튼을 눌러 조절합니다. Home 조명이 2 번 깜박이면 설정이 완료됩니다. 초기 기본 속도로 돌아오려면 조합이 중복됩니다.
컨트롤러 초기화	M + Home 버튼 4초간 길게 누르기	컨트롤러 초기화 후 장치 재부팅

⚠ 다음 주의 사항을 주의 깊게 읽어주시기 바랍니다

- 작은 부품이 있습니다. 3세 이하 어린이 손에 닿지 않는 곳에 두십시오. 삼키거나 흡입할 때는 즉시 의사의 도움을 받으십시오.
- 제품을 고온에서 사용하지 마십시오.
- 화기 근처에 두지 마십시오.
- 제품을 습하거나 먼지가 많은 곳에 두지 마십시오.
- 제품을 무리하게 구부리거나 떨어뜨리지 마십시오.
- 제품을 부분적 또는 완전히 분해하지 마십시오.
- 제품을 청소할 때에는 부드러운 천을 사용하십시오. 알코올, 벤젠, 희석제 또는 연마제는 사용하지 마십시오.
- 충전 중에는 제품을 사용하지 마십시오. 충전 중에 사용하면 감전, 화재 또는 배터리 손상의 위험이 있습니다.
- 습한 환경에서 충전하지 마십시오.
- 충전 중에는 제품을 덮지 마십시오.
- 충전 중에는 제품을 방치하지 마십시오.
- 충전 중 이상 징후가 발견되면 즉시 충전을 중단하십시오.
- 충전 중 제품이 뜨거워지면 충전을 중단하십시오.
- 충전 중 제품을 떨어뜨리지 마십시오.
- 충전 중 제품을 구부리지 마십시오.
- 충전 중 제품을 분해하지 마십시오.
- 충전 중 제품을 개조하지 마십시오.
- 충전 중 제품을 청소하지 마십시오.
- 충전 중 제품을 사용하지 마십시오.
- 충전 중 제품을 방치하지 마