

NEEWER[®]



Photography Softbox Lighting Kit
Instruction Manual

Copyright

© 2024 Shenzhen Neewer Technology Co., Ltd. All Rights Reserved.

This document is the sole property of Shenzhen Neewer Technology Co., Ltd and shall not be, reproduced, transmitted, transcribed, stored in a retrieval system or translated in any form, by any means, without prior written permission from Shenzhen Neewer Technology Co., Ltd. Shenzhen Neewer Technology Co., Ltd reserves the right to change content in this instruction manual at any time and without prior notice.

Version Control

Date	Version number	Description	Issued by
03/06/2024	1.0	Photography Softbox Lighting Kit Manual	NEEWER®

Package Contents

NK300

Softbox ×1
Tripod ×1
Light bulb ×1
Carrying bag ×1

NK200

Softbox ×2
Tripod ×2
Light bulb ×2
Carrying bag ×1

Assembly Steps

1. Installing the tripod




- ① Hold the center column of the tripod and pull the legs outwards.



- ② Ensure the legs are fully extended as shown.




- ③ Extend the telescopic bar to adjust to the required height.



- ④ Use the flip locks to secure each segment of the main bar.

Assembly Steps

2. Installing the softbox



- ① Unfold the softbox and mount it on the tripod.



- ② Insert the bulb into the softbox light socket.



- ③ Attach the diffusion panel to the front of the softbox.



- ④ The installation is complete.

Operating Instructions



Connect to a power source and turn on the switch to use.

Safety Notes

1. Do not tear the product during use.
2. Please do not use it near fire source and flammable places.
3. After assembling the product, please fix the support to prevent falling.

This document is a translation of the original instruction manual created by the manufacturer.

Detailed information on the distributor's / manufacturer's warranty terms and conditions is available at website <https://serwis.innpro.pl/gwarancja>

The product must be regularly maintained (cleaned) by the user himself or by specialised service centres at the user's expense and expense. In the absence of information on necessary cyclical maintenance or service actions in the operating instructions, the deviation of the physical condition of the product from a physically new product must be assessed regularly, at least once a week. If any discrepancy is detected or found, maintenance (cleaning) or service measures must be taken urgently. Failure to properly maintain (clean) and react when a dissimilar condition is detected may result in permanent damage to the product. The guarantor is not liable for damage resulting from negligence.

Warnings and safety information

All information regarding the use of the product can be found in the user manual. Before using it, read its contents and follow the instructions contained therein.

Also read the following information before use:

Warnings for use

Risk of damage to the equipment:

- Do not expose the equipment to moisture or extreme temperatures - this can lead to damage to electrical and mechanical components.
- Ensure tripods and mounts are properly secured and placed on a stable surface to prevent them from tipping over and damaging lamps or other accessories.
- Do not expose the product to shocks, impacts, falls or other factors that may contribute to damage.
- Do not expose the product to water unless the manufacturer declares it waterproof. If this is the case, regularly check that all closures and seals are in good condition and show no signs of wear.

Risk to children:

- Products used in the photographic studio, such as lamps, stands, shadowless tents and backdrops, are not for play and are not intended for children.
- Keep the product out of the reach of children to prevent accidental damage to the equipment or choking on small parts.

Risk of electric shock:

- Never handle cords or plugs with wet hands. Failure to do so may result in electric shock.
- Use only compliant power sources that meet the technical requirements of the equipment.
- Regularly check cords and plugs for damage - if problems are noted, replace them before further use.

User safety:

- Avoid looking directly at the light source, especially in the case of high-powered lamps - this can damage your eyesight.
- When assembling or dismantling equipment, make sure components such as tripods and lamps are well secured to avoid accidental falls or injury.
- Avoid touching hot lamp surfaces immediately after use - they can reach high temperatures and cause burns.

Information on correct use

Setting up equipment in the studio:

- Lamps and softboxes should be positioned at a safe distance from flammable materials such as photographic backgrounds made of paper or fabric.
- For shadowless tents and tripods, make sure all components are assembled correctly to avoid shifting or tipping over.
- Set up your equipment in an area with adequate ventilation, especially for heat-generating lights, to avoid overheating.

Storage and transport:

- When you have finished working, store the equipment in a dry and clean place, away from dust, heat sources and moisture to prevent damage.
- When transporting lamps, tents and softboxes, use suitable covers or cases to protect them from mechanical damage.

Additional precautions

Maintenance and cleaning:

- Clean your equipment regularly, especially the surfaces of reflectors, softboxes and lamps, using a soft cloth to remove dust and dirt.
- Do not use strong chemicals that may damage materials or protective coatings on the equipment.

Service:

- If you have problems with the operation of the equipment, contact an authorised service centre. Do not attempt to repair them yourself.

Safe disposal:

- Dispose of used light bulbs and other items of photographic equipment in accordance with local electronic waste regulations.
- Do not dispose of the equipment in municipal waste - contact your local electronics collection point.

If you require additional information about the product, please contact customer service (e-mail: hurt@innpro.pl, website: <https://innpro.pl/>) or another specialist.

Environmental protection



Electronic waste labelled in accordance with the European Union directive must not be placed together with other municipal waste. It is subject to separate collection and recycling at designated points. By ensuring that it is disposed of correctly, you will prevent potential negative consequences for the environment and human health. The collection system for used equipment complies with local environmental regulations for waste disposal. You can obtain detailed information on this subject from your municipality, your purification plant or the shop where you purchased the product.



The product complies with the requirements of the so-called New Approach Directives of the European Union (EU), which deal with issues relating to safety of use, health protection and environmental protection, specifying the hazards that should be detected and eliminated.

Importer: **INNPRO**

INNPRO Robert Błędowski sp. z o.o.
Rudzka 65c

44-200 Rybnik, Poland

tel. +48 533 234 303

hurt@innpro.pl

www.innpro.pl

Manufacturer:

Shenzhen Neewer Technology Co.,Ltd.

Lu Shan Building Block A Room 1903

No. 3023 Shenzhen, Guangdong, China

vip@neewer.com

EU Representative:

NW Formations GmbH

Hoferstrasse 9B

71636 Ludwigsburg, Germany

office.nwformations@gmail.com