

AM6 PRO


Mini Electric Air Pump

User Manual

Air Pump User Manual

I List

- ① Mini Air Pump
- ② Quick release FV
- ③ Storage bag
- ④ FV/AV air hose
- ⑤ Ball needle
- ⑥ TYPE-C Charging Cable




I About Charging

- 1. Make sure you unplug the Type-C charging cable when the device is fully charged.
- 2. To charge the device safely, please use a charger that has the following certification mark. [CCC、FCC、CE、Rosh]
- 3. In charging mode, the battery indicator lights on the screen will light up in sequence: red light > blue light > green light. When fully charged, the green light will remain lit.
- 4. For first-time use or after prolonged non-use, charge the air pump before inflating.

Indicator light	Green light	Blue light	Red light
Battery power	60~100%	30~60%	1%~30%


Function Introduction



Type-C
Charging Port



Hose Installation



Air Pressure Settings



Starting inflation

Double-click the [Power] button while the device is on to start inflation. When the target pressure is reached, inflation will automatically stop.

Hold down the [On/Off] button

After use, hold down the [Power] button to turn off the device. If no operations are performed within 1 minute while the device is on, it will automatically shut down.

Press the [+] button to increase air pressure, press the [-] button to decrease air pressure. The screen displays the target air pressure value, and after 3 seconds, it returns to displaying the current air pressure value.

Simultaneously press the [+] and [-] buttons briefly to switch between air pressure units (PSI or BAR). Hold down the [+] and [-] buttons simultaneously to turn the lighting on/off.

Notes

1. It is normal for the air nozzle to get hot when the equipment is switched on! To avoid burns, do not touch the metal air nozzle!
2. If the product inflates for 1 minute and the pressure value remains below 5 PSI, it will automatically shut down to prevent continuous ineffective operation.

3. If the internal temperature exceeds the upper limit, the product will stop working, and the screen will display the character 【HO】 . It is recommended to wait for the product to cool down before use.
4. If the screen displays 【LO】 , it indicates that the battery is low and needs to be charged promptly.
5. In high-altitude areas, negative values may be displayed. Press the power button five times in quick succession to calibrate and reset to zero.
6. This product is not waterproof. Please take precautions in daily use.
7. The AM6 PRO is not a toy. Please do not allow children to use it unsupervised by adults to avoid injury.
8. This product comes with a one-year quality warranty. Disassembly or damage caused by human error may result in the inability to receive after-sales service or incur repair costs.
9. For any product quality or usage issues, please contact the sales merchant or our after-sales email: cyclami@outlook.com

E-Mail : cyclami@outlook.com

Address: 2nd Industrial Building, 7th floor, No. 16, JINGLE Road
Xiangzhou District, Zhuhai City, Guangdong Province.



- www.cyclami.com -



AM6 PRO Specifications

Current	1~5A
Battery	800mAh 7.4V
Charging	Type-C 5V-1.5A
Size	75x46.3x31.5mm
Weight	≈171.2g
MAX Inflation	Max 150PSI