CYCLAMI

Professional bicycle tire pry bar

售后邮箱：cyclami@cyclami.com　　官网：www.cyclami.com

电话：0756-2177677　　地址：广东省珠海市香洲区景乐路16号第二工业大厦7层

微信公众号
扫描二维码
在线客服解答

Tire Removal Usage:

Use the multi-function pry bar to pry out the outer tyre, then slide along the wheel frame to remove the outer tyre.



Mounting the tyre Usage:

Use the pry bar to snap into the wheel frame, then slide along the wheel frame to mount the outer tyre.






Disassemble the outer tire wheel frame slot
Install the outer tire wheel frame slot
CYCLAMI
AV release position
Hexagonal spoon head x 4
25
35
30
20

Bicycle Tire Lever

EN: Scan the QR code to view the detailed user manual.

DE: Scannen Sie den QR-Code, um die detaillierte Bedienungsanleitung anzuzeigen.

SV: Skanna QR-koden för att se den detaljerade användarhandboken.

FR: Scannez le code QR pour voir le manuel d'utilisation détaillé.

IT: Scansiona il codice QR per visualizzare il manuale utente dettagliato.

DA: Scan QR-koden for at se den detaljerede brugermanual.

CS: Skenování QR kódu pro zobrazení podrobné uživatelské příručky.

PL: Skanuj kod QR, aby zobaczyć szczegółową instrukcję obsługi.

QC PASS 检03

✉ E-mail: cyclami@outlook.com 🌐 Web: www.cyclami.com

Address: 7th Floor, Second Industrial Building, No. 16 Jingle Road, Xiangzhou District, Zhuhai City, Guangdong Province, China