

hohem

iSteady

M7

AI Tracking Smartphone Gimbal

Quick Start Guide V1.0

WE ARE HERE FOR YOU

Connect us at Facebook

www.hohem.com

Subscribe for More Information

Shenzhen Hohem Technology Co., Ltd.

ADD: B106, Building 2, Jiuxianglin Industrial Park, 4227 Xili Lake Road,
Xili Street, Nanshan, Shenzhen City, Guangdong, China

WEB: www.hohem.com
EMAIL: service@hohem.com

1. Scan before Using

Hohem Joy App

Tutorial

User Manual

- Scan QR code for user tutorials.
- QRコードをスキャンしてユーザー向けチュートリアルを確認してください。
- 사용자 튜토리얼을 위해 QR 코드를 스캔하세요.
- QR-Code scannen für Benutzeranleitungen.
- Scansiona il codice QR per i tutorial utente.
- Scannez le code QR pour les tutoriels utilisateur.
- Escanea el código QR para tutoriales de usuario.
- Escaneie o código QR para tutoriais de usuário.
- Сканируйте QR-код для получения инструкций пользователя.

CALL CENTER

-Toll Free

UNITED STATES: +1(888)9658512	Mon-Fri: 9:00AM-5:00PM(EST)
UNITED KINGDOM: +44(0)808 2737578	Mon-Fri: 2:00PM-10:00PM(GMT +0)
CANADA: +1(855)758 8939	Mon-Fri: 9:00AM-5:00PM(EST)
BRAZIL: +55 (0)800 5911897	Mon-Fri: 10:00AM-6:00PM(GMT -3)

❶ Powering On

Video Tutorial

3s Long press

Power Button

2. Charging

Charging time: Approx. 3 hours

USB-Type C

5V-3A
Not included.

4. Bluetooth Connection

OTHER DEVICES

IM7-XXXXXXX

To pair an Apple Watch

3. Mounting & Powering On

Compatible smartphones: ≤ 7 inches (weight: ≤ 500g, width: 58mm-90mm, thickness: ≤ 12.5mm)

❶ Tripod Installation & Axes Unlocking

5. Usage Modes

❶ Handheld Mode

❷ Extended Mode

❸ Remote Mode

*The remote automatically connects with the gimbal via Bluetooth by default.

❷ Mounting & Balancing (Landscape)

Video Tutorial

6. Buttons on the Handle

Power Button
Long press: On/Off
Single press: Reverse charging
(in power off state)
Double press: Enter/Exit standby mode
Press five times: Auto gimbal calibration

Trigger
Single press: ❶Start AI tracking
(used in preview with tracking target selected)
❷Pause/Resume AI tracking
(used in preview during tracking)
Double press: Recenter the gimbal
Triple press: Forward-facing/Backward-facing phone position
Press four times: Ultra-Wide-Angle Mode
Press and hold: All Lock Mode
Single press + Press and hold: Sports Mode


❸ Mounting & Balancing (Portrait)

Side Roller
*Press the button to select the function, then rotate the roller for smooth adjustment.
❶Fill Light Control
Long press: Turn on/off the fill light
Triple press: Switch to CCT/RGB
Single press: Submenu switch (brightness/color)
❷Motor Rotation
Double press: Select motor control
(under focus and motor control)
Single press: Submenu switch (pan/tilt/roll)
❸Focus Control
Double press: Select focus control
(under focus and motor control)



A-B Button
*Used to set start and end points for motion timelapse shots.
Long press: Set A/B point
Single press: Quickly return to A/B point
Double press: Smoothly rotate to A/B point
*The default rotation time is 1 minute, which can be modified through Hohem Joy app or touchscreen.

7. AI Tracker

❶ Powering On



❷ Gesture Control





❸ Person and Object Tracking

*Ensure that the AI tracker is turned on.




Video Tutorial





Tips: ① You also can drag-select the target and single press the side button/trigger to start AI tracking.
② During tracking, single press the side button/trigger to pause/resume AI tracking.
③ Triple tap the screen to stop AI tracking.

❹ Front/Rear Tracking





8. Buttons on the Remote




9. Touchscreen Interface

Home



10. Indicators



11. Official APP Download (Free)

